



ASHWEK
AUTOMATION

RS 232 TO USB HID CONVERTER



**WEIGHT DATA IS DIRECTLY TRANSFERRED TO THE CURSOR IN REAL-TIME,
ENSURING IMMEDIATE AVAILABILITY AND USABILITY OF THE DATA.**



Connectivity

Compatible with all Windows operating systems.



Plug and Play

Determine a structured business plan



www.ashwek.com



ashwek@gmail.com



91 9920595791



Mumbai



ASHWEK AUTOMATION

PRODUCT FEATURES

Sequence of Operation

- Place the weight scale on a stable surface.
- Ensure the USB connection is properly established between the weight scale and the computer/device.

Dual Transfer Mode

- Manual Transfer Mode: Press the star (*) key to manually initiate data transfer, providing control over the weighing process.
- Auto Transfer Mode: Automatically transfers stable weight data, ensuring convenience and efficiency.

Data Transfer:

- In both manual and auto modes, the weight data will be transferred through USB HID to the connected computer/device.
- The data is transmitted in a format recognized by the receiving software, ensuring compatibility and ease of use.

Data Integrity

- The system is designed to avoid human mistakes and prevent data manipulation.
- The weight data is directly transferred from the scale to the computer/device, ensuring accurate and unaltered data.

Accurate Data Transfer

- Utilizes USB HID for reliable and precise data transmission directly to your computer or device, eliminating the need for additional software or drivers.

User-Friendly Interface

- Simple and intuitive operation with minimal steps, making it easy for users of all experience levels to operate the scale.

Versatile Application

- Suitable for a wide range of applications, including industrial, commercial, and laboratory settings where precise weight data is critical.



www.ashwek.com



ashwek@gmail.com



91 9920595791



Mumbai